

# LOAD-MASTER *LITE*

## LML-C

### LOAD CELL SYSTEM USER GUIDE

H100\_D535a



#### **Force Logic UK Ltd**

N4 Lambs Farm Business Park, Swallowfield, RG7 1PQ, UK  
+44 (0) 118 988 8807 info@force-logic.co.uk www.force-logic.co.uk

## KEY FUNCTIONS

- ON/OFF** Press briefly to switch on. 'Yes' displayed to indicate correct operation, then live reading displayed. Previously stored TARE value is remembered.  
Press briefly to switch off.  
(Auto switch-off after 20 mins. of no activity)
- TARE** Press to remove tare weight and set the display to zero. This is a permanent tare, un-tared value cannot be recalled.
- UNITS** Press to switch between engineering units. Arrow indicates 'tonnes'. No arrow indicates 'kN'.  
(Other units available on request).
- PEAK** Press to display only maximum measured load. Right-hand digit flashes 'P' while activated.  
Press again to return to live reading mode.

## WARNING INDICATIONS

- 'Lobt'** Indicates low battery condition.
- 'HELP'** Over-range indication. Indicated when load cell rated capacity is exceeded by 2%

**(If overload occurs, do not use load cell and return to supplier for inspection and calibration )**

Yearly inspection and re-calibration is advised to ensure correct operation and safe use.

For **calibration** or **service**, return to:

**Force Logic UK Ltd**

N4 Lambs Farm Business Park  
Swallowfield  
Berkshire  
RG7 1PQ  
+44 (0) 118 988 8807  
service@force-logic.co.uk

**SPECIFICATIONS**

DISPLAY UNITS	kilogram / Newton
CABLE LENGTH	10M
MAX. ERROR	0.25 % of reading
WORKING LOAD LIMIT	1 x rated capacity
SAFETY FACTOR	5 x rated capacity
BATTERY (handset)	1 x PP3 9V (6LR61)
BATTERY (load cell)	None
BATTERY LIFE	250 hours minimum

**SAFE USE**

**LOAD-MASTER** is designed to accept all makes of Safety Bolt Shackle. Check that shackles are of correct load rating relative to the maximum capacity of the load cell. Check that the pin is the correct diameter for the load cell attachment hole bushes.

Whichever hardware is used to attach the load cell, always ensure they are of adequate strength to carry the maximum load of the load cell.

For lifting applications or overhead weighing, correct working practices should be followed as per published regulations.

**LOAD-MASTER** load cells are proof loaded prior to calibration to ensure compliance and safety of the load measurement operation. They are supplied with a Certificate of Calibration & Conformity valid for 1 year. It is recommended they be returned to the address below for re-calibration after 1 year to ensure correct operation and measurement accuracy as per the specifications. A new Certificate of Calibration & Conformity will be issued.

Do not use the device if any of the stated warning indications are displayed. If the unit is suspected of being damaged, faulty, or has been overloaded, it should be immediately returned for inspection and re-calibration.

## WARRANTY

This equipment is provided with 1 year warranty from date of supply, against manufacturing or operational defects, when used in accordance with manufacturers instructions and specifications.

This warranty does not cover misuse, accidental damage, incorrect installation, or damage in transit. Faults arising from these conditions will be considered on an individual basis on return of the faulty item.

The device should not be altered, modified or adapted in any way as to affect it's operation or use.

Any repair or calibration should be carried out by the manufacturer or manufacturers authorised persons.

## DECLARATION OF CONFORMITY

Complies with the essential requirements and all other relevant provisions of the following directives:

EMC Directive 2004/108/EC.

R&TTE Directive 1999/5/EC.

Machinery Directive 2006/42/EC



## RoHS

Under Category 9 of Directive 2002/95/EC all components are fully compliant where necessary.

## WEEE

These products should be disposed of at a designated collection point for the correct recycling of electrical and electronic equipment under the European Union WEEE Directive 2012/19/EU.

